



Pole Ideal Pars Co.
www.medpip.com

Cool Box

Storing different materials in temperatures between 0 and 4°C

Cool Box is an insulated container which provides appropriate temperature conditions based on Cold Chain Technology for storing different medicines and vaccines, blood and its derivatives, and generally all temperature-sensitive substances. This product is available in two models of 11L and 30L which can contain 26 and 70 ice packs (400g each) respectively. The inner insulation is made from

expanded polystyrene and the body is made from polyethylene. The 11L model has a dual-purpose handle for easy transport and locking the lid (by turning the handle upward), while in the 30L model, the lid gets locked by two latches each at one side of the box and there are two handles on the other two sides for easy transport. Both models have an average body thickness of 25mm.



GS1 Code	Capacity	Inner Dimensions (mm)	Outer Dimensions (mm)
6260807500774	11 L	330 × 195 × 180	430 × 265 × 230
6260807502259	30 L	480 × 290 × 250	560 × 370 × 300



1st floor, No.12, Naghdi St., Jahantab St., Motahari Ave, Tehran, Iran

Postal code:1576635714

P.O. Box:15875-9483 FAX:+98 21 88765561 /+98 21 88767159

Tel: 88765847 - 88765915 - 88545922-9

info@medpip.com

www.medpip.com

@poleideal

@poleideal

+98912 334 0197

Pole Ideal Pars Co.